




How to check Magnavox MWD200F fuses

Written By: Taryn





TOOLS:

- [Tweezers](#) (1)
-

Step 1 — How to remove Magnavox MWD200F cover




- Using a Philips screwdriver, remove the two screws on the top of the device, towards the back.

Step 2



- Remove the plastic cover by pulling up on the back and away from the faceplate.

Step 3



- Remove the face plate by unclipping the latches on the bottom of the device. Once it's unlatched, simply pull the face plate off.

Step 4 — How to check Magnavox MWD200F fuses



- Now that the device is open, you can check for any blown fuses that may need to be replaced.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-09 03:27:57 AM.